

TABLE OF CONTENTS

SECTION 1 – INTRODUCTION1

SECTION 2 – SYSTEM DESCRIPTION2

 LANDING GEAR SWITCH2

 LANDING GEAR INDICATOR LIGHTS3

 LANDING GEAR CIRCUIT BREAKER3

 LANDING GEAR ACTUATOR3

 ACTUATOR LIMIT SWITCHES4

 DOWN INDICATOR SWITCHES4

 LANDING GEAR SAFETY SWITCH4

 MANUAL EXTENSION SYSTEM4

SECTION 3 – THEORY OF OPERATION5

 PLACING GEAR SWITCH IN UP POSITION6

 PLACING GEAR SWITCH IN DOWN POSITION7

 MANUAL EXTENSION SYSTEM7

SECTION 4 – ROUTINE SERVICE8

 INSPECTION INTERVALS8

 LUBRICATION10

 SERVICING MAIN LANDING GEAR SHOCK STRUTS13

 SERVICING NOSE GEAR SHOCK STRUT14

 SERVICING SHIMMY DAMPER15

 INSPECTION AND SERVICING OF BRAKES16

 WHEEL ALIGNMENT18

 RIGGING PROCEDURES20

SECTION 5 – DIAGNOSIS AND TROUBLESHOOTING30

The information contained in this reference book is not intended to be used as technical data for aircraft servicing. It is based on data available at the time of publication. Always refer to the current published service manual, service letters, and service newsletters for technical servicing information for the appropriate aircraft.



Section 1-Introduction

This reference manual is one part of a technician training program on multi-engine landing gear for the 300-400 series Cessna aircraft.

This program is designed to provide a servicing technician with the technical knowledge he needs to inspect, service, troubleshoot, and repair the landing gear system currently used on 300-400 series aircraft.

A tape/filmstrip is used with this reference manual as a part of the total program. This program is designed to include using the applicable Cessna Service Manual in conjunction with the tape/filmstrip and this reference manual.

This manual is divided into five sections, as follows:

Section 1 – Introduction

Section 2 – System Description

Section 3 – Theory of Operation

Section 4 – Routine Service

Section 5 – Diagnosis and Troubleshooting

Section 2 presents a description of the major components of the landing gear system.

Section 3 provides a description of what occurs throughout the landing gear system when the landing gear switch is placed in the UP and DOWN positions, and when the manual extension system is used.

Section 4 includes a table of inspection intervals for performing required maintenance on the landing gear system. There are also service procedures presented for certain areas of the landing gear.

In addition, this section includes rigging procedures, one of the most important services to perform on landing gear. The procedures for rigging are presented in a new type of format called the Symbol/Picture Diagnosis/Repair, or SPDR for short. This format has been proven to be more effective as both a learning tool and in practice. Complete instructions are provided for understanding and using SPDR's.

Section 5 presents a series of diagnosis problems. These are problems that can be considered more hazardous than just a nuisance. These are also presented in the new SPDR format.

While using this manual, if you come across a situation requiring more detailed information about the landing gear system, please refer to the Cessna Service Manual.

Section 2-System Description

The landing gear system is almost identical for all 300 and 400 series aircraft. Figure 1 shows the general location of the main components.




Figure 1 Landing Gear System—300-400 Series

LANDING GEAR SWITCH

The landing gear switch (Figure 2) is a three position switch which is operated by being pulled out and moved up or down. A wheel shaped knob is provided for easier gripping. The top position (UP) is for raising the gear, the lower position (DOWN) is for extending the gear, and the center position (OFF) is a neutral position.




Figure 2 Landing Gear Switch and Module Type Indicator Lights

System Description

LANDING GEAR INDICATOR LIGHTS

There are four landing gear indicator lights (Figure 2); one upper red one and three lower green ones. The upper light glows when any or all of the gear are in an unlocked position. Each gear is indicated by one of the green lights, which glow when the gear is fully extended and locked. All lights out means the landing gear is in the up position.

Current 400 series and the 340 have modular type indicators as shown in Figure 2. Earlier 400 series and the 310 have individual lights as shown in Figure 3. Both types of lights serve the same function, and both types are activated by position indicators on the gear.




Figure 3 Indicator Lights—Individual Bulb Type

LANDING GEAR CIRCUIT BREAKER

Since the landing gear system is electrically operated, it is protected by a push-to-reset type of circuit breaker (Figure 4). If an overload occurs in the circuit, the heat rise causes the circuit breaker to pop out, thereby opening the circuit. This panel is located left of the pilot's seat.




Figure 4 Landing Gear Circuit Breaker

LANDING GEAR ACTUATOR

The landing gear actuator (Figure 5) is driven by an electric motor and reduction unit. Each landing gear is mechanically connected to the actuator, and is raised and lowered by the action of the actuator. On all 300 and 400 series aircraft, except for the 340, the bellcrank, to which the main landing gear drive tubes are connected, is attached to the top part of a sector shaft running vertically through the actuator. The bellcrank for the nose gear is attached to the bottom part of the sector shaft.




Figure 5 Actuator Limit Switches on Actuator

System Description

On the 340, the bellcranks are reversed. The one for the nose gear is attached to the top of the sector shaft, and the one for the main gear is attached to the bottom of the shaft.

A resistor, shown in Figure 5, reduces the speed of the electric motor in the down cycle of the landing gear.

ACTUATOR LIMIT SWITCHES

There are two adjustable limit switches (Figure 5) mounted to the top of the actuator. These switches control overtravel of the landing gear by opening the electrical circuits when the correct amount of up or down travel has been reached.

DOWN INDICATOR SWITCHES

There is a down indicator switch on each main gear and one on the nose gear (Figure 6). When the gear reaches its down position, these switches are activated and cause the three green landing gear indicator lights on the instrument panel to glow.




Figure 6 Gear Down Indicator Switches

LANDING GEAR SAFETY SWITCH

Also known as a squat switch, this switch, (Figure 7) which is mounted on the left main gear, prevents accidental raising of the gear. As long as the weight of the aircraft is on the gear, this switch remains activated and the gear won't go up.

CAUTION: *Even though the aircraft is provided with this safety switch, do not move the landing gear switch out of the down position when the aircraft is on the ground.*




Figure 7 Landing Gear Safety Switch

MANUAL EXTENSION SYSTEM

A manual extension system (Figure 8) is provided for extending the gear in case the electrical operating system doesn't work. A handcrank is located to the right of the pilot's seat. When the handcrank is unfolded to its operating position, it disengages an actuator gear from the electrical operating system and allows the landing gear to be extended manually. Pressing a pushbutton on the handcrank releases the handcrank so it can be placed in the stowed position again. As the handcrank is placed in the stowed position, the actuator gear is again engaged with the electrical operating system.




Figure 8 Landing Gear Manual Extension System

Section 3-Theory of Operation

This section contains a brief description of the operation of the landing gear system for three different modes:

- Placing gear switch to UP position.
- Placing gear switch to DOWN position.
- Manually extending the gear.

For the first two modes, refer to Figures 9 and 10. Figure 9 is a simplified diagram of the components operated by the electrical system. Figure 10 shows the mechanical components involved in raising and lowering the gear. For a complete electrical schematic of the landing gear system, refer to the Cessna Service Manual.




Figure 9 Landing Gear Electrical System

Theory of Operation




Figure 10 Landing Gear System Linkage

PLACING GEAR SWITCH IN UP POSITION

When the gear switch is placed in the UP position, power is supplied from the gear motor circuit breaker through the landing gear safety (squat) switch to the landing gear relay. The relay closes, supplying power to the landing gear motor. The motor then drives the actuator, through the reduction unit, in a clockwise direction. At the same time, power is supplied to the gear unlocked light, causing the light to glow red.

As the actuator turns clockwise, the bellcranks begin pulling the landing gear linkage tubes inward, raising the gear. When the gear reaches the full retract position, the bellcrank activates the actuator up limit switch. This interrupts the circuit, causing the landing gear relay to open and cutting power to the landing gear motor. The gear unlocked light also goes out.

Theory of Operation

PLACING GEAR SWITCH IN DOWN POSITION

When the gear switch is placed in the DOWN position, power is supplied from the gear motor circuit breaker, through the actuator down limit switch, directly to the landing gear motor and then through the relay and landing gear resistor to ground. The motor then drives the actuator, through the reduction unit, counterclockwise. At the same time, power is supplied to the gear unlocked light, causing the light to glow red.

As the actuator turns, the bellcrank begins moving the gear linkage drive tubes outward, lowering the gear. The gear is prevented from lowering too quickly by a resistor which slows down the gear motor.

As the gear reaches full extend position, the inboard drive tube activates the actuator down limit switch, cutting off power to the gear motor. At the same time, a down indicator switch is activated for each gear, causing a gear down green light to glow. When all three landing gear are down and locked, all three gear down lights will be on, and will remain on as long as the gear is fully extended down and locked. The red gear unlocked light will have gone out.

MANUAL EXTENSION SYSTEM

If the electrical operating system for the gear should fail, the manual system can be used to lower the gear. Opening the crank disengages an actuator gear from the electrical operating system, as shown in Figure 11. Turning the crank clockwise then lowers the landing gear to the full down position. Placing the crank back into the stowed position again engages the actuator gear with the electrical operating system.




Figure 11 Engaging Manual Extension System

Section 4-Routine Service

In this section are those maintenance services that must be performed at scheduled intervals. A chart is included for inspection intervals of all the major components of the landing gear system.

Complete inspection and rigging procedures are also included. A new type of format called the Symbol/Picture/Diagnosis/Repair (SPDR) is used

to present the rigging section. Instructions on using this format are given at the beginning of the rigging section. Read them carefully and you shouldn't have any problem with the format.

For additional service procedures, refer to the Cessna Service Manual.

INSPECTION INTERVALS

Items to be Inspected and/or Serviced	Frequency in Hours			Special Inspection
	50	100	200	
Main Landing Gear System – Check actuating time and motor (Flight Check)	X			
Main Landing Gear Actuator – Inspect for condition, security, and wiring for condition routing, and support			X	
Main Landing Gear Actuator – Service		X		
Emergency Main Extension System – Inspect for condition, operation and specification compliance			X	
Emergency Manual Extension System Support Bearings – Service				C
Emergency Manual Extension System Spool and Bellcrank – Service				C
Emergency Manual Extension System Crank Handle Linkage – Service				D
Emergency Manual Extension System Mitergear – Service				C
Main and Nose Landing Gear Assemblies – Inspect for condition	X			
Rigging Landing Gear System – Perform landing gear inspection.			X	
Nose and Main Gear Shock Struts – Check for evidence of leakage, proper extension; Check strut barrel for corrosion, pitting, and cleanliness	X			
Shock Struts – Service			X	

- A – Every 50 hours or sooner when local dust conditions exist.
- B – First 100 hours and 200 hours thereafter.
- C – Every 500 hours.
- D – Every 1500 hours.

Routine Service


INSPECTION INTERVALS (Cont.)

Items to be Inspected and/or Serviced	Frequency in Hours			Special Inspection
	50	100	200	
Torque Links – Inspect for wear and condition			X	
Torque Links Nose and Main Gear Service	X			
Nose and Main Gear Retraction Linkage – Inspect for condition			X	
Nose Gear Trunnion Fitting – Service		X		
Nose and Main Gear Wheel Bearings – Service		XB		
Nose Gear Pivot Bushings – Service		X		
Nose and Main Gear All Spherical Rod Ends – Service		X		
Nose Gear Shimmy Damper – Check for leakage and attach points for wear and condition	X			
Nose Gear Shimmy Damper – Service		XB		
Nose Wheel Steering System – Check cable tension, travel and gimbal bolts for condition and torque		X		
Nose Gear Fork – Inspect for cracks, general condition and security of attachment			X	
Nose and Main Wheel and Tires – Check wear, pressure and condition	XA			
Main Gear Side Brace – Service		X		
Main Gear Uplock Bushings – Service		X		
Main Gear Thrust Washers – Service				C
Brakes – Perform operational check of main and parking brake system	X			
Brake System Plumbing – Inspect for leaks, condition and security. Check for proper routing and support.		X		
Brake Assemblies – Check wear of lining and disc warpage.		X		
Brake Master Cylinders – Service		X		
Parking Brake Handle Shaft and Pivot Points – Service				

- A – Every 50 hours or sooner when local dust conditions exist.
- B – First 100 hours and 200 hours thereafter.
- C – Every 500 hours.
- D – Every 1500 hours.

Routine Service

LUBRICATION



NOTE: WIPE POLISHED SURFACE OF LANDING GEAR SHOCK STRUT WITH A CLEAN DRY CLOTH AS REQUIRED

NOTE: UNDER EXTREME CONDITIONS CLEAN AND LUBRICATE WHEEL BEARINGS EVERY 100 HOURS


ITEM NO.	ITEM DESCRIPTION	LUBE TYPE	APPLICATION	NUMBER OF FITTINGS IN AREA
1.	Main Gear Bushings	OG	Oil Can	—
2.	Wheel Bearings	GW	Hand Pack	—
3.	Torque Link Fittings	GL	Gun	6
4.	All Spherical Rod Ends	GL	Hand	—
5.	Thrust Washers	OG	Oil Can	—
6.	Side Brace	GL	Gun	2

OG — Oil, General Purpose (MIL-L-7870)
 GW — Grease, Wide Temperature Range (MIL-G-81322)
 GL — Grease, Low Temperature (MIL-G-21164)

Figure 12 Lubrication of Main Landing Gear

Routine Service

LUBRICATION (Cont.)



ITEM NO.	ITEM DESCRIPTION	LUBE TYPE	APPLICATION	NUMBER OF FITTINGS IN AREA
1.	Trunnion Fitting	GL	Gun	1
2.	Torque Link	GL	Gun	4
3.	Wheel Bearing	GW	Hand Pack	—
4.	Pivot Bushings	OG	Oil Can	—
5.	All Spherical Rod Ends	GL	Hand	—

OG — Oil, General Purpose (MIL-L-7870)
 GW — Grease, Wide Temperature Range (MIL-G-81322)
 GL — Grease, Low Temperature (MIL-G-21164)


Figure 13 Lubrication of Nose Gear

Routine Service


LUBRICATION (Cont.)

NOTE: WHEN GREASING THIS FITTING REMOVE THIS BOLT TO PREVENT BREAKING SEAL. REINSTALL WHEN FINISHED GREASING

NOTE: APPROXIMATELY 3 PUMPS ON A HAND GREASE GUN WILL GIVE ADEQUATE LUBRICATION




LANDING GEAR ACTUATOR



NOTE: 1. AFTER LUBRICATING, WIPE OFF EXCESS LUBRICANT ADJACENT TO CRANKING HANDLE

2. DO NOT OIL THE CHAIN; AN OILED CHAIN MAY COLLECT DIRT AND GRIT. WIPE CHAIN WITH A CLEAN DRY CLOTH



MANUAL EXTENSION (LANDING GEAR)

ITEM NO.	ITEM DESCRIPTION	LUBE TYPE	APPLICATION	NUMBER OF FITTING IN AREA
1.	Landing Gear Actuator	GL	Gun	2
2.	Support Bearings	OG	Oil Can	—
3.	Spool and Bellcrank	GL	Hand	—
4.	Crank Handle Linkage	OG	Oil Can	—
5.	Miter Gear	GL	Hand	—

GL — Grease, Low Temperature (MIL-G-21164)
 OG — Oil, General Purpose (MIL-L-7870)

Figure 14 Lubrication of Landing Gear Actuator and Manual Extension

Routine Service

SERVICING MAIN LANDING GEAR SHOCK STRUTS

1. Position the aircraft on Jacks (refer to the Jacking Procedures in the Cessna Service Manual).
2. Deflate the strut by loosening the valve body (Figure 15) a maximum of 2 1/2 turns.
3. With the strut fully compressed, remove the valve and fill the strut with hydraulic fluid (MIL-H-5606A).
4. Stroke the strut slowly a minimum of three times.
5. With the strut compressed, top off the fluid.
6. Replace the valve and inflate the strut to 300 PSI (Model 421 to 275 PSI) with the tire clear of the ground.
7. Remove aircraft from Jacks.

NOTE: *If strut has to be serviced when aircraft is on the ground, service the strut to approximately 4.55 inches (Model 421 to approximately 2.75 inches) extension until it can be serviced with aircraft on Jacks.*




Figure 15 Servicing Main Landing Gear Shock Struts

Routine Service

SERVICING NOSE GEAR SHOCK STRUT

1. Position the aircraft on Jacks (refer to the Jacking procedures in the Cessna Service Manual).
2. Deflate the strut by loosening the valve body (Figure 16) a maximum of 2 1/2 turns.
3. With the strut fully compressed, remove the valve and fill the strut with hydraulic fluid (MIL-H-5606A).
4. Stroke the strut slowly a minimum of three times.
5. Replace the valve and inflate the strut to 165 PSI (Model 421 to 65 PSI) with the tire clear of the ground.
6. Remove the aircraft from Jacks.

NOTE: *If strut has to be serviced when aircraft is on the ground, service the strut to approximately 2.60 inches extension until it can be serviced with aircraft on jacks.*




Figure 16 Servicing Nose Gear Shock Strut

Routine Service

SERVICING SHIMMY DAMPER




Figure 17 Shimmy Damper—Normal Position

1. Use a tow bar and turn the nose wheel strut to the extreme left position against the 55 degree stop. This places the shimmy damper piston to the rear of the cylinder (Figure 18) and eliminates the possibility of entrapped air in the cylinder.




Figure 18 Shimmy Damper—Piston in Rear of Cylinder

2. Remove filler plug (Figure 18) from the cylinder and fill the cylinder with hydraulic fluid (MIL-H-5606A). Keep filling the cylinder until it overflows. Then you'll know it is full.
3. Replace the filler plug and turn the nose wheel strut through its entire travel several times.
4. Return strut to the extreme left position against the 55 degree stop.
5. Remove the filler plug and add whatever fluid is needed to fill the cylinder.
6. Replace and safety wire the filler plug.

Routine Service

INSPECTION AND SERVICING OF BRAKES




Figure 19 Landing Gear Brake System

1. Check brake system plumbing (Figure 19):
 - a. Inspect fittings for damaged threads and deformed flares on ends of tubing.
 - b. Inspect lines for cracks, dents, deep scratches, flattened bends, and signs of chafing.
 - c. Inspect hoses for swelling, cracking, abrasions through protective plies and leaks.

Routine Service

2. Check Master Cylinder

- a. Inspect metal parts for wear and thread damage.
- b. Inspect cylinder walls for corrosion, pitting and scores.
- c. Inspect O-ring seal and O-ring portion of lock-o-seal for swelling, chipping or other evidence of damage.

3. Check brake lining wear limits as follows:

- a. Set the parking brake to force the brake disc against the anvil lining.
- b. Check clearance between outboard surface of brake disc and flat surface of brake housing.
- c. Replace linings if space is, or exceeds, 3/8 (0.375) inch.

4. Check brake disc wear limits as follows:

- a. Inspect disc for wear. Discard disc when worn to a thickness of 0.225 inch or less.
- b. Inspect disc for dishing. Disc must be replaced if dishing exceeds 1/16 (.0625) inch.
- c. Inspect disc keyways for wear and battering. Replace disc if keyway width exceeds 1.188 inch.

NOTE: *Where applicable, check drive keys for wear. If drive keys are worn to a minimum width of 1.116 inches, replace them. Always replace drive keys as a set.*

5. Clean brake system

- a. Clean hydraulic components with clean system hydraulic fluid or denatured alcohol.
- b. Wash metal parts in suitable solvent.
- c. Wash O-rings with clean system hydraulic fluid or denatured alcohol.
- d. If required, clean brake linings with MEK.

6. Repair brake system

- a. Replace worn or damaged parts.
- b. Polish out minor nicks, using 400 grit wet-or-dry sandpaper with system hydraulic fluid.
- c. Replace brake linings at each engine overhaul or when wear approaches limits described in Inspection/Check.
- d. Replace master cylinder body when damage to cylinder wall is found.
- e. Repair of master cylinder components is not recommended, only replacement of defective parts.

NOTE: *For repair procedures, refer to the Cessna Service Manual.*

Routine Service

WHEEL ALIGNMENT

1. Position the aircraft with the main wheels resting on grease plates. For each set of grease plates, use two aluminum sheets approximately 18 inches square with sufficient grease spread between them to permit the top plates to slide freely on the bottom plates.
2. Set a straightedge in place against the main wheel tires at axle height (Figure 20). This can be a beam, 2 x 4, or anything else that is straight. You can position it on blocks, bricks, or whatever is available as long as it is at the same height for both wheels.
3. Place one leg of a carpenter's framing square against the straightedge and the other leg against the inboard side of the wheel being checked. Measure the distance from the framing square leg adjacent to the wheel, to wheel rim at the extreme aft circumference of the wheel rim. The difference between the two measurements will be the toe-in or toe-out for that wheel. Toe-out for either wheel is $.06 \pm .05$ inch. Toe-out must remain in tolerance throughout the entire range

of free play in the system. If tolerance cannot be retained, replace bushings. Refer to Disassembly/Assembly of Main Landing Gear in the Cessna Service Manual.

NOTE: *Remove weight from gear by jacking aircraft before attempting to add or remove washers to torque links.*

4. Reposition washers between torque links to correct for excessive toe-in. Wheel alignment after adjustment must be within limits prescribed in Step 3.

Combinations of thick and thin washers can be used between the torque links to obtain the correct wheel alignment. Washers that are added or removed between the torque links must also be removed or added to the outside end of the spacer to maintain an .004 to .020 side play of the torque links. Be sure that the spacer washers are centered on the spacer as the nut is being torqued up to proper value.

Routine Service





Figure 20 Wheel Alignment

RIGGING PROCEDURES

Introduction

This section presents a systematic method for rigging Cessna 300 and 400 Multi-engine landing gear. These rigging charts are different from the ones you have used before. These charts use pictures and symbols, plus a few words, to take you through each procedure, step-by-step.

Here is an example of some of the symbols you will see:




Each symbol tells you to do something. Make sure you do what the symbol tells you to do.

Using the Charts

The charts are divided into three sections: STEP, PROCEDURE and RESULT




Always start with STEP 1 and go through the complete procedure from left to right. This is an example of a step:



The first thing you would do in this step is raise the landing gear 20° to 30° using the switch on the control panel. The symbol then tells you to remove the attaching nuts from the actuator arms in the nose gear and main gear doors. That's all you have to do in that step. The RESULT column tells you what step to go to next. In this case you would go directly to STEP 2.

Work through each step until the system is completely rigged and you reach this sign (STOP).



READ THIS—BEFORE STARTING INSPECTION

NOSE AND MAIN LANDING GEAR RIGGING INSPECTION.

The nose and main landing gear rigging inspection should be performed indoors with proper jacks, 28 volt external power supply, 0 to 150 pound spring scale and an 0880001 actuator arm tension tool available.

If aircraft is equipped with an hour meter, the fuse for the hour meter must be pulled before starting the inspection. Refer to the Cessna Service Manual for fuse location.





The aircraft should be placed on jacks, the necessary access plates, seats, carpets, floorboards removed, and the landing gears cleaned with a suitable solvent prior to inspection. Step by step procedures are presented and each stop must be completed before performing the next step.

NOTE: The operational checks and tension measurements requirements of this inspection will require the services of two people.




CAUTION: WHEN OPERATING THE LANDING GEAR ALWAYS BE PREPARED TO STOP TO PREVENT DAMAGE TO THE SYSTEM.

IF ANY MAJOR COMPONENTS OF THE LANDING GEAR SYSTEM REQUIRE REMOVING, REFER TO THE CESSNA SERVICE MANUAL FOR INSTRUCTIONS.

DISCONNECTING: Landing Gear Doors

STEP	PROCEDURE	RESULT
<p>1</p> 	<p>NOSE GEAR DOOR</p> <p>MAIN GEAR DOOR</p> 	<p>2</p>
<p>2</p> 	<p>● RUN LANDING GEAR DOWN</p>  <p>NOTE SUPPORT IN-BOARD DRIVE TUBE DURING GEAR BOX OPERATION</p>	<p>3</p>

CHECKING: Up and Down Limit Switches

<p>3</p> <ul style="list-style-type: none"> ● OPERATE LANDING GEAR TO UP AND LOCKED POSITION ● TURN SWITCH OFF ● ENGAGE MANUAL EXTENSION CRANK  	 <p>● TURN HANDLE (CCW) AFT UNTIL THE INTERNAL UP STOP IN THE ACTUATOR IS REACHED APPROXIMATELY 3/4 TO 1 1/2 TURNS</p> <p>STOW HANDLE BEFORE ENGAGING GEAR MOTOR</p> <p>NOTE ANGULAR POSITION OF CRANK HANDLE</p>	<p>5</p> <p>OK</p> <p>INTERNAL STOP REACHED 3/4 TO 1 1/2 TURNS</p> <p>4</p> <p>OK</p> <p>INTERNAL STOP NOT REACHED 3/4 TO 1 1/2 TURNS</p>
--	--	---



STEP

PROCEDURE

RESULT

4

● RUN LANDING GEAR DOWN

ADJUST UP LIMIT SWITCH UNTIL CORRECT NUMBER OF TURNS ARE OBTAINED

NOTE: EACH TIME THE ACTUATOR SWITCHES ARE ADJUSTED, LANDING GEAR MUST BE OPERATED APPROXIMATELY HALF WAY DOWN THEN BACK UP BEFORE NOTING THE NUMBER OF TURNS REQUIRED TO REACH THE INTERNAL STOP




5

5

● OPERATE LANDING GEAR TO DOWN AND LOCKED POSITION

● TURN SWITCH OFF

● ENGAGE MANUAL EXTENSION CRANK

TURN HANDLE (CW) FWD. UNTIL THE INTERNAL DOWN STOP IN THE ACTUATOR IS REACHED. APPROXIMATELY 1 TO 2 TURNS

NOTE ANGULAR POSITION OF CRANK HANDLE

INTERNAL STOP REACHED 1 TO 2 TURNS



INTERNAL STOP NOT REACHED 1 TO 2 TURNS

7

6

6

ADJUST DOWN LIMIT SWITCH UNTIL CORRECT NUMBER OF TURNS ARE OBTAINED

DURING MANUAL EXTENSION OF THE LANDING GEAR NEVER RELEASE THE MANUAL EXTENSION CRANK. DAMAGE CAN RESULT TO PERSONNEL AND THE SKIRT OF THE PILOT'S SEAT

RECONNECT INBOARD DRIVE TUBE ONLY



7

CHECKING: Drive Tubes, Trunnions, Retracting Linkage, and Wheel Well area

7

CHECK LANDING GEAR OPERATION

VISUALLY INSPECT THE FOLLOWING FOR NICKS DENTS, BENDS, CRACKS WEAR, LOOSENESS, DEEP SCRATCHES AND ANY OTHER DAMAGE

DRIVE TUBES

TRUNNIONS IDLERS AND RETRACTION LINKAGE

PIVOT PIN AND ROLL PIN INSTALLED

CHECK FOR LOOSENESS

ALL OK

ANY NOT OK



REJECT

REPAIR OR REPLACE



8

8





CHECKING: Main Gear Door Actuator Arm Tension Gear Down

STEP	PROCEDURE	RESULT
8	 <p>CHECK MAIN GEAR DOORS FOR TENSION</p>	 <p>TENSION SHOULD BE 25 ± 10 POUNDS</p> <p>OK — 9 TENSION OK</p> <p>OK — 10 TENSION NOT OK</p>

CHECKING: Main Door Actuator Arm Tension Gear Up

9	 <p>CHECK MAIN GEAR DOORS FOR TENSION</p>	 <p>TENSION SHOULD BE 25 ± 10 POUNDS IN UP POSITION AND A MAXIMUM OF 10 POUNDS DIFFERENCE FROM DOWN POSITION</p> <p>OK — 12 TENSION OK</p> <p>OK — 10 TENSION NOT OK</p>
---	--	--

ADJUSTING: Main Door Arm Actuator Tension Gear Up and Gear Down

10	 <p>ADJUST INBOARD DRIVE TUBE ROD END IN 1/2 TURN INCREMENTS</p> <p>(CCW) INCREASES TENSION DOWN POS. DECREASES TENSION UP POS.</p> <p>(CW) DECREASES TENSION DOWN POS. INCREASES TENSION UP POS.</p>	 <p>RECHECK TENSION</p> <ul style="list-style-type: none"> ● WITH <u>GEAR DOWN</u> AND ● WITH <u>GEAR UP</u> <p>TENSION SHOULD BE 25 ± 10 POUNDS IN BOTH POSITIONS AND A MAXIMUM OF 10 POUNDS DIFFERENCE BETWEEN UP TENSION AND DOWN TENSION</p> <p>OK — 12 TENSION OK</p> <p>OK — 11 TENSION NOT OK</p>
11	 <p>ADJUST UP LIMIT SWITCH TO OBTAIN PROPER TENSION ONLY IF IT CANNOT BE OBTAINED BY ROD ADJUSTMENT</p> <p>INCREASE TENSION</p> <p>DECREASE TENSION</p>	 <p>AFTER OBTAINING PROPER TENSION CHECK HAND CRANK FOR NUMBER OF TURNS TO INTERNAL STOP 3/4 TO 1 1/2 TURNS</p> <p>STOP REACHED 3/4 TO 1 1/2 TURNS — 12</p> <p>STOP NOT REACHED 3/4 TO 1 1/2 TURNS — 3 GO BACK</p>

CHECKING: Main Landing Gear Free Fall

STEP	PROCEDURE	RESULT
12	BREAK MAIN LOCK LINKS	OK → 15 GEAR LOCKS OK → 13 GEAR DOES NOT LOCK
13	VISUALLY CHECK THE FOLLOWING: <ol style="list-style-type: none"> 1 DRIVE TUBES FOR BENDS, BREAKS BINDING AND DAMAGE. 2 TRUNNION PINS FOR SEIZING BINDING, ALIGNMENT AND LUBRICATION. 3 LOCK LINK BRACE FOR ALIGNMENT, OVERCENTER TRAVEL, BENDING AND BREAKS 4 SIDE BRACE FOR PROPER OVERCENTER ENGAGEMENT, BOLTS FOR PROPER TORQUE (REFER TO TORQUE CHART, CHAPTER I) 5 BOLTS IN WHEEL WELL AREA FOR BINDING AND INTERFERENCE 	OK → 15 ALL OK OK → 14 ANY NOT OK
14	REJECT QUESTIONABLE PARTS	REPAIR OR REPLACE AS NECESSARY → 15

ADJUSTING: Main Landing Gear Free Fall

15	LENGTHEN END FITTING IN 1/2 TURN INCREMENTS UNTIL GEAR WILL NOT FREE FALL AND LOCK	OK → 16 LIGHTS WHEN GEAR LOCKS
SHORTEN END FITTINGS IN SMALL INCREMENTS TO ALLOW GEAR TO FALL AND LOCK. SIDE BRACE LINKS MUST GO OVERCENTER	CHECK GEAR DOWN INDICATOR LIGHT	OK → 16 LIGHTS BEFORE GEAR LOCKS OK → 16 ADJUST LIGHT (SEE STEP 34)

CHECKING: Landing Gear Drop Off

16	CONNECT INTERMEDIATE DRIVE TUBES	OK → 18 DROP OFF OK
LOOSEN AND EXTEND HOOKS OUT OF THE WAY	OPERATE LANDING GEAR UP	OK → 17 DROP OFF NOT OK
MEASURE DROP OFF (SHOULD BE 1/8 TO 1/4 INCHES)		

STEP

PROCEDURE

RESULT

<p>17</p> <p>ADJUST INTERMEDIATE DRIVE TUBE</p> <p>LENGTHEN TO DECREASE DROP OFF</p> <p>SHORTEN TO INCREASE DROP OFF</p>	<p>RECONNECT INTERMEDIATE DRIVE TUBE AND RECHECK DROP OFF</p>	<p>18</p>
--	---	-----------

CHECKING: Down Lock Tension

<p>18</p> <p>PULL AT RIGHT ANGLES TO LOCK LINK</p>	<p>CHECK MAIN LANDING GEAR DOWN LOCK FOR PROPER ENGAGEMENT AND TENSION (40 TO 60 LBS)</p> <p>PLACE FINGER ON DOWN LOCK SWITCH</p>	<p>READ SCALE AT POINT WHEN A DEFINITE SWITCH ACTUATION IS FELT</p> <p>OK TENSION OK</p> <p>NOT OK TENSION NOT OK</p>	<p>20</p> <p>19</p>
--	---	---	---------------------

ADJUSTING: Down Lock Tension

<p>19</p> <p>ADJUST OUTBOARD DRIVE TUBE TENSION TO (40-50 LBS) IN 1/2 TURN INCREMENTS</p> <p>(CCW) DECREASES TENSION AND LENGTHENS TUBE</p> <p>(CW) INCREASES TENSION AND SHORTENS TUBE</p>	<p>FORK BOLT</p>	<p>NOTE:</p> <ul style="list-style-type: none"> IF YOU LENGTHEN TUBE YOU MUST SHORTEN FORK BOLT SAME AMOUNT OF TURNS IF YOU SHORTEN TUBE YOU MUST LENGTHEN FORK BOLT SAME AMOUNT OF TURNS <p>NOTE:</p> <p>IF DOWN LOCK TENSION IS ADJUSTED RECHECK LANDING GEAR DROPOFF</p>	<p>16</p>
---	------------------	---	-----------













CHECKING: Uplock Hooks For Engagement

<p>20</p> <p>RECONNECT MAIN GEAR UPLOCK HOOK</p>	<p>CHECK UPLOCK HOOKS FOR PROPER ENGAGEMENT WHEN GEAR IS RETRACTED</p>	<p>OK HOOKS ENGAGE PROPERLY</p> <p>NOT OK HOOKS DO NOT ENGAGE PROPERLY</p>	<p>23</p> <p>21</p>
--	--	--	---------------------






ADJUSTING: Uplock Hooks For Engagement

<p>21</p> <p>DISCONNECT UPLOCK PUSH - PULL TUBE</p>	<p>ADJUST UPLOCK PUSH - PULL TUBE UNTIL HOOKS MAKE FULL CONTACT WITH SPACERS</p> <p>(CCW) PULL HOOKS AWAY FROM SPACERS</p> <p>(CW) PULL HOOKS CLOSER TO SPACERS</p>	<p>UPLOCK HOOKS MUST ENGAGE AND DISENGAGE FREELY WITH NO BINDING</p>	<p>22</p>
---	---	--	-----------






CHECKING: NOSE GEAR IDLER BELLCRANK FOR LOOSENESS

STEP	PROCEDURE	RESULT	
22  CHECK IDLER BELLCRANK FOR LOOSENESS	 NOT LOOSE		
	 TIGHTEN BOLT	 NOT LOOSE	
	 TIGHTEN BOLT	 LOOSE	
	 TIGHTEN BOLT	 LOOSE REPAIR OR REPLACE BELLCRANK	







CHECKING: Nose Gear Connector Link For Overcenter Travel

23  DISCONNECT DRIVE TUBE AND ASSIST SPRING APPLY SLIGHT FORCE IN DIRECTION OF ARROW	LINK SNAPS FIRMLY OVERCENTER 	
	LINK DOES NOT SNAP FIRMLY OVERCENTER 	






ADJUSTING: Nose Gear Connector Link For Overcenter Travel

24 ADJUST ROD END UNTIL LINK SNAPS OVERCENTER 	 RECONNECT ROD END	
 (CCW) LENGTHENS ROD END AND INCREASES FORCE  (CW) SHORTENS ROD END AND DECREASES FORCE		

CHECKING: NOSE GEAR RETRACTION

25  SWING NOSE GEAR INTO UP POSITION BY HAND	 PUSH CONNECTOR LINK OVERCENTER IN DIRECTION OF ARROW AND CHECK RETRACTED POSITION	 RETRACTED POSITION OK	
		 RETRACTED POSITION NOT OK	

ADJUSTING: NOSE GEAR RETRACTION



26  DISCONNECT ADJUSTING ROD END AND ADJUSTING FORK	ADJUST ADJUSTING ROD END IN 1/2 TURN INCREMENTS TO OBTAIN PROPER RETRACTION POSITION   (CCW) LENGTHENS ADJUSTING ROD END AND RAISES RETRACTED POSITION  (CW) SHORTENS ADJUSTING ROD END AND LOWERS RETRACTED POSITION	NOTE: COMBINED LENGTH OF ADJUSTING ROD END AND ADJUSTING FORK MUST REMAIN UNCHANGED ● IF YOU LENGTHEN ADJUSTING ROD END YOU MUST SHORTEN ADJUSTING FORK THE SAME AMOUNT ● IF YOU SHORTEN ADJUSTING ROD END YOU MUST LENGTHEN ADJUSTING FORK THE SAME AMOUNT	
---	---	--	---

CHECKING: Nose Gear Down Lock Tension



STEP

PROCEDURE



RESULT

<p>27</p>  <p>CONNECT NOSE DRIVE TUBE</p>	<p>CHECK NOSE GEAR DOWN LOCK TENSION</p>  <p>READ SCALE WHEN LOCK BREAKS OVERCENTER TENSION SHOULD BE 25 ± 10 POUNDS</p>	<p>OK — 29 TENSION OK</p> <p>OK — 28 TENSION NOT OK</p>
---	---	---


ADJUSTING: Nose Gear Downlock Tension

<p>28</p>  <p>DISCONNECT NOSE DRIVE TUBE AT FORK BOLT</p> <p>ADJUST FORK BOLT IN 1/2 TURN INCREMENTS TO OBTAIN PROPER TENSION</p> <p>(CCW LENGTHENS BOLT AND INCREASES TENSION)</p> <p>(CW) SHORTENS BOLT AND DECREASES TENSION</p>		<p>29</p>
---	---	------------------


CHECKING: Nose Gear Uplock Tension

<p>29</p>  <p>CHECK NOSE GEAR UPLOCK TENSION (75 + 10, - 15 POUNDS)</p>	 <p>READ SCALE WHEN CONNECTOR LINK BREAKS OVERCENTER</p>	<p>OK — 31 TENSION OK</p> <p>OK — 30 TENSION NOT OK</p>
---	--	---





ADJUSTING: Nose Gear Uplock Tension

<p>30</p>  <p>DISCONNECT FORWARD DRIVE TUBE</p> <p>ADJUST DRIVE TUBE IN 1/2 TURN INCREMENTS TO OBTAIN PROPER TENSION</p> <p>(CCW) LENGTHENS TUBE AND DECREASES TENSION</p> <p>(CW) SHORTENS TUBE AND INCREASES TENSION</p>	<p>NOTE:</p> <ul style="list-style-type: none"> ● IF YOU LENGTHEN TUBE YOU MUST SHORTEN FORK BOLT SAME AMOUNT OF TURNS ● IF YOU SHORTEN TUBE YOU MUST LENGTHEN FORK BOLT SAME AMOUNT OF TURNS 	<p>31</p>
--	--	------------------


CHECKING: Nose Gear Uplock Engagement

STEP	PROCEDURE		RESULT
<p>31</p>  <p>CHECK NOSE GEAR UPLOCK FOR PROPER ENGAGEMENT</p>	<p>PROCEDURE</p> <p>.003 TO .060 INCHES CLEARANCE BETWEEN SPACER AND HOOK SURFACE TO ADJUST LOOSEN BOLTS AND ADJUST HOOK</p> <p>HOOK MUST ENGAGE AND DISENGAGE FREELY WITHOUT BINDING</p>	<p>OK → ENGAGEMENT RECONNECT OK</p> <p>OK → ASSIST SPRING</p> <p>OK → ENGAGEMENT NOT OK</p>	<p>32</p> <p>26</p>


CHECKING: Gear Down Indicator Light Switches For Proper Adjustment

<p>32</p> <p>RETRACT LANDING GEAR APPROXIMATELY HALFWAY</p> <p>MOVE SWITCH TO CENTER POSITION</p>  <p>ENGAGE MANUAL EXTENSION HANDLE AND CRANK TOWARD DOWN POSITION UNTIL GREEN LIGHT COMES ON</p>	 <p>NOTE ANGULAR POSITION OF MANUAL HANDLE</p>	 <p>WHEN A LIGHT COMES ON CHECK THAT GEAR IS DOWN AND LOCKED WITH OVERCENTER LINKAGE OVERCENTER</p>	<p>33</p>				
<p>33</p> <p>RESUME CRANKING TOWARD DOWN POSITION</p> <ul style="list-style-type: none"> NOTE NUMBER OF TURNS REQUIRED TO REACH THE INTERNAL STOP IN THE ACTUATOR <table border="1" data-bbox="406 1008 876 1197"> <tr> <td>NOSE GEAR</td> <td>NOT LESS THAN 8 OR MORE THAN 14</td> </tr> <tr> <td>MAIN GEAR</td> <td>NOT LESS THAN 4 OR MORE THAN 8</td> </tr> </table> 	NOSE GEAR	NOT LESS THAN 8 OR MORE THAN 14	MAIN GEAR	NOT LESS THAN 4 OR MORE THAN 8		<p>NOSE GEAR OK → OK</p> <p>NOSE GEAR NOT OK → OK</p> <p>MAIN GEAR OK → OK</p> <p>MAIN GEAR NOT OK → OK</p>	<p>36</p> <p>34</p> <p>36</p> <p>35</p>
NOSE GEAR	NOT LESS THAN 8 OR MORE THAN 14						
MAIN GEAR	NOT LESS THAN 4 OR MORE THAN 8						


ADJUSTING: Nose Gear Down Indicator Light Switch

<p>34</p>  <p>ADJUST SWITCH ACTUATING BOLT</p>	<p>(CCW) ACTUATES SWITCH FARTHER FROM THE INTERNAL STOP INSIDE THE ACTUATOR</p> <p>(CW) ACTUATES SWITCH CLOSER TO THE INTERNAL STOP INSIDE THE ACTUATOR</p> <p>NOTE: AFTER ADJUSTMENT CHECK TO SEE THAT LIGHT COMES ON SAME TIME THAT GEAR LOCKS</p>	<p>36</p>
--	--	------------------



ADJUSTING: Main Landing Gear Indicator Light Switch

<p>35</p>  <p>ADJUST SWITCH REPOSITION SWITCH</p> <p>AWAY FROM BELLCRANK</p> <p>TOWARD BELLCRANK</p>	<ul style="list-style-type: none"> TOWARD BELLCRANK ACTUATES SWITCH FARTHER FROM INTERNAL STOP INSIDE THE ACTUATOR AWAY FROM BELLCRANK ACTUATES SWITCH CLOSER TO INTERNAL STOP INSIDE THE ACTUATOR <p>NOTE: AFTER ADJUSTMENT CHECK TO SEE THAT LIGHT COMES ON SAME TIME THAT GEAR LOCKS</p>	<p>36</p>
--	---	------------------

CHECKING: Nose and Main Landing Gear Doors For Proper Fit

STEP	PROCEDURE	RESULT
<p>36</p> <ul style="list-style-type: none"> ● OPERATE LANDING GEAR THROUGH ONE CYCLE AND CHECK GEAR INDICATOR LIGHTS AND WARNING HORN ● CHECK FOR OPERATION WITH GEAR EXTENDED AND RETRACTED 	<ul style="list-style-type: none"> ● RECONNECT DOORS ● OPERATE LANDING GEAR THROUGH ONE CYCLE  <p>CHECK FOR PROPER FIT - SHOULD BE UP SNUG - NOT DEFLECTED IN TOO TIGHT CHECK FOR DAMAGE</p> <ul style="list-style-type: none"> ● CHECK THAT WARNING HORN SOUNDS WITH FLAPS BELOW 15 DEGREES 	<p>37</p>

CHECKING: Safety Switch Inspection

<p>37</p> <ul style="list-style-type: none"> ● REFER TO CESSNA SERVICE MANUAL FOR CHECKING AND ADJUSTMENT OF LANDING GEAR SAFETY SWITCH 	<p>AFTER COMPLETING THE INSPECTION MAKE SURE THE GEAR IS DOWN AND LOCKED, LUBRICATED AND POWER TURNED OFF.</p> <p>NOTE: IF ADJUSTMENTS WERE MADE, MAKE SURE ALL BOLTS HAVE BEEN TORQUED, COTTER PINS INSTALLED AND DOORS CONNECTED, BEFORE INSTALLING ACCESS PLATES, FLOORBOARDS, SEATS, CARPETS AND REMOVING AIRCRAFT FROM JACKS.</p>	
---	--	---


Section 5-Diagnosis and Troubleshooting

This section contains diagnosis procedures for a series of problems which could prove hazardous. Additional diagnosis problems are included in the Cessna Service Manual.

This section uses the new Symbol/Picture/Diagnosis/Repair format rather than previously used conventional formats. An explanation of how to use these charts is provided. Read it carefully before beginning the charts.


INTRODUCTION

This section presents a systematic method of diagnosing and troubleshooting the Multi-Engine Electric Landing Gear System. This new method uses pictures, words and symbols, where applicable, to help you follow procedures.




USING THE CHARTS

The charts are divided into three sections: STEP, PROCEDURE and RESULT.



Always start at the first step 1 and go through the complete procedure from left to right following each symbol and its meaning as outlined in the preceding column.







Work through each step until the system is repaired and you reach this sign





PROBLEM: GEAR WARNING HORN FAILS TO SOUND


(Landing Gear Up and Throttles Retarded)

STEP	PROCEDURE	RESULT
<p>1</p>  <p>CHECK FOR OPEN CIRCUIT BREAKER</p>	<p>MAKE CONTINUITY CHECK OF ELECTRICAL SYSTEM (SEE SERVICE MANUAL)</p>  <p>RESET CIRCUIT BREAKER</p>	<p>2</p> <p>STOP</p> <p>STOP</p>
<p>2</p>  <p>CHECK GEAR DOWN SWITCH ADJUSTMENT</p>	<p>CHECK FOR DEFECTIVE GEAR DOWN SWITCH</p>  <p>ADJUST GEAR DOWN SWITCH</p>	<p>3</p> <p>STOP</p> <p>STOP</p>
<p>3</p>  <p>CHECK THROTTLE MICROSWITCH ADJUSTMENT</p>	<p>CHECK FOR DEFECTIVE THROTTLE MICROSWITCH</p>  <p>REPLACE HORN</p> <p>REPLACE MICROSWITCH</p> <p>ADJUST MICROSWITCH</p>	<p>STOP</p> <p>STOP</p> <p>STOP</p>




PROBLEM: GEAR DOWN (GREEN) LIGHTS FLICKER WHEN GEAR IS DOWN

(Actuate Landing Gear to Down Position)
























PROBLEM: GEAR DOWN (GREEN) LIGHT FAILS TO LIGHT

(Actuate Landing Gear to Down Position)



PROBLEM: LANDING GEAR SHIMMIES DURING FAST TAXI, TAKEOFF OR LANDING

STEP	PROCEDURE	RESULT
<p>1</p>  <p>CHECK SHIMMY DAMPER MOUNTING</p>	<p>OK  </p> <p>CHECK FLUID LEVEL IN SHIMMY DAMPER</p> <p>OK </p> <p>OK  SERVICE DAMPER</p> <p>OK  REPAIR OR REPLACE PARTS AS NECESSARY</p>	<p>2</p> <p>STOP</p> <p>STOP</p>
<p>2</p>  <p>CHECK FOR INTERNAL BYPASSING OF FLUID IN SHIMMY DAMPER</p>	<p>OK  </p> <p>CHECK ROLL PIN</p> <p>OK </p> <p>OK  REPLACE DAMPER</p> <p>OK  REPLACE ROLL PIN</p> <p>OK  REPLACE DEFECTIVE PARTS</p>	<p>3</p> <p>STOP</p> <p>STOP</p>
<p>3</p>  <p>LANDING GEAR DOES NOT SHIMMY</p>  <p>LANDING GEAR STILL SHIMMIES</p> <p>CHECK TIRE BALANCE</p>	<p>OK  </p> <p>CHECK WHEEL BEARINGS</p> <p>OK  REPLACE BEARINGS</p> <p>OK  BALANCE TIRES</p>	<p>STOP</p> <p>4</p> <p>STOP</p> <p>STOP</p>
<p>4</p> <p>CHECK FOR EXCESSIVE CLEARANCE BETWEEN UPPER AND LOWER TORQUE LINKS</p> 	<p> REPAIR OR REPLACE PARTS AS NECESSARY</p>	<p>STOP</p>



PROBLEM: LANDING GEAR FAILS TO RETRACT OR EXTEND AND GEAR MOTOR DOES NOT OPERATE

(With Normal Voltage Applied, Actuate Landing Gear)

STEP	PROCEDURE	RESULT
1	<p>CHECK FOR OPEN CIRCUIT BREAKER OR LOW BATTERY VOLTAGE</p> <p>CHECK CONTINUITY OF LANDING GEAR ELECTRICAL SYSTEM (SEE SERVICE MANUAL)</p> <p>RESET CIRCUIT BREAKER OR RECHARGE BATTERY</p>	<p>2</p> <p>STOP</p> <p>STOP</p>
2	<p>CHECK ADJUSTMENT OF THE FOLLOWING</p> <p>GEAR SAFETY SWITCH</p> <p>ACTUATOR LIMIT SWITCHES</p> <p>REPLACE MOTOR</p> <p>ADJUST SWITCHES</p>	<p>STOP</p> <p>STOP</p>





PROBLEM: LANDING GEAR FAILS TO RETRACT OR EXTEND AND GEAR MOTOR OPERATES

(With Normal Voltage Applied, Actuate Landing Gear)

STEP	PROCEDURE	RESULT
1	<p>CHECK THAT MANUAL CRANK IS PROPERLY STOWED</p> <p>CHECK REDUCTION UNIT OUTPUT SHAFT PIN FOR SHEARING</p> <p>STOW PROPERLY</p> <p>REPLACE LANDING GEAR ACTUATOR</p> <p>REPLACE PIN</p>	<p>STOP</p> <p>STOP</p> <p>STOP</p>



PROBLEM: MANUAL EXTENTION SYSTEM FAILS TO EXTEND LANDING GEAR

(With Landing Gear Retracted)

STEP	PROCEDURE	RESULT
1	 <p>CHECK MANUAL CRANK FOR FULL ENGAGEMENT</p> <p>OK → [Checkmark] → [OK] → [2]</p> <p>OK → [Checkmark] → [Wrench] → [STOP]</p> <p>OK → [Wrench] → [STOP]</p> <p>ADJUST LINKAGE (AND OR) ACTUATOR AND REPLACE DEFECTIVE PARTS</p> <p>ADJUST MANUAL EXTENSION LINKAGE AND REPLACE DEFECTIVE PARTS</p>	2
2	 <p>CHECK LANDING GEAR RIGGING (SEE RIGGING CHARTS)</p> <p>[Wrench] → [STOP]</p> <p>REPAIR AS NECESSARY</p>	STOP


PROBLEM: LANDING GEAR FAILS TO RETRACT OR EXTEND COMPLETELY



(With Normal Voltage Applied, Actuate Landing Gear)

STEP	PROCEDURE	RESULT
1	 <p>CHECK FOR OPEN CIRCUIT BREAKER BECAUSE OF INCORRECT RIGGING</p> <p>OK → [Wrench] → [STOP]</p> <p>OK → [Wrench] → [STOP]</p> <p>ADJUST UP OR DOWN LIMIT SWITCHES</p> <p>RESET CIRCUIT BREAKER AND RERIG LANDING GEAR SYSTEM</p> 	STOP
		STOP

PROBLEM: LANDING GEAR FAILS TO RETRACT OR EXTEND

(With Normal Voltage Applied, Actuate Landing Gear)



STEP	PROCEDURE	RESULT
1	 <p>CHECK FOR OPEN CIRCUIT BREAKER</p> <p>OK → [ACTUATOR MOTOR TURNS BUT GEAR FAILS TO RESPOND] → [2]</p> <p>OK → [Wrench] → [STOP]</p> <p>RESET CIRCUIT BREAKER</p>	2
		STOP

STEP	PROCEDURE	RESULT
<p>2</p>  <p>CHECK THAT MANUAL CRANK IS PROPERLY STOWED OR RIGGED</p>	 <p>SEE TROUBLESHOOTING LANDING GEAR ACTUATOR</p> <p>STOW CRANK PROPERLY OR RERIG SYSTEM</p>	<p>STOP</p>

Aircraft  on Jacks

Chart 10

PROBLEM: ONE LANDING GEAR FAILS TO RETRACT OR EXTEND COMPLETELY
 (With Normal Voltage Applied, Actuate Landing Gear)

STEP	PROCEDURE	RESULT
<p>1</p>  <p>CHECK LINKAGE TO AFFECTED GEAR</p>	 <p>RERIG ENTIRE SYSTEM (SEE RIGGING CHARTS)</p> <p>REPLACE LINKAGE AND RERIG ENTIRE SYSTEM (SEE RIGGING CHARTS)</p>	<p>STOP</p> <p>STOP</p>